



KitchenAid Professional 600 Top Cover Replacement

Written By: Luke



Step 1 — Top Cover



- Take out the screw which holds on the silver band using a Phillips #2 screwdriver.
- Remove the silver band.

Step 2



- Remove the four Phillips #2 screws located around the mixer where the band was removed.
- ⓘ This picture only shows two of the screw that you need to remove. The other two are on the exact opposite side of the mixer.

Step 3



- Remove the top of the mixer to reveal the inner parts.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 01:16:04 AM.